

1 BACKGROUND:

- 1.1 Entel are upgrading their HX LCD display to a "Type 2" display (HT radios are not affected).
- 1.2 A new Bootloader and the latest firmware **MUST** be installed once the LCD is fitted (see below).
- 1.3 For instructions on "How To Update The Software For A Type 2 LCD" see www.entel.co.uk.

2 SOFTWARE UPDATING:

- 2.1 After fitting a Type 2 LCD please install the latest Bootloader (HX_TYPE2_LCD_ONLY_BOOTLOADER.fw).
- 2.2 Update the Firmware – Please download and install the latest firmware into the radio.


All files are available from: www.entel.co.uk/updates

3 IDENTIFICATION:

Type 1 – Existing LCD Display



Type 2 – New LCD Display



Please Note: Please reuse or replace the two rear LCD cushions (part no. 9403040510A) as these act as an insulator.